

4006N

DIAMOND SHARP

- Ergonomic side edge sharpener
- Pocket size, «on the slope» use also
- Easy handling, steady grip, maximum accuracy
- Best results, minimum effort
- Right and left hand use
- For ski and snowboard
- Spare Diamond Medium **5190**



- STEP 1** Remove rock damaged spots and burrs. Best if used with water or with a polishing solution.
- STEP 2** Polish and super finish the ski and snowboard edges. Best if used with water or with a polishing solution.



side + base tuning

4005

COMBI SHARP

- Ergonomic side and base edge sharpener
- Easy handling, steady grip, maximum accuracy
- Best results, minimum effort
- Right and left hand use
- For ski and snowboard
- Spare file 80 mm **5104**

